

G.C Default Plan

	INPUT	Chara	stand
1	OH L	451	210
2	OH R	451	210
3	F.T	e604	-
4	L.T	e604	-
5	H.T	e604	-
6	HH	451	Crip
7	SN Top	57	259
8	SN Bot	57	Crip
9	Kick in	B91A	-
10	Kick out	B52	259
11	EB L	D.out or DI	-
12	EB M	58	Crip
13	EG 1	57	259
14	EG 2	57	259
15	Key L/1	MIX out or DI	-
16	Key R/2	MIX out or DI	-
17			
18			
19			
20			
21			
22			
23			
24			
25	Vox 1<<	58	210
26	Vox 2<	58	210
27	Vox 3 main	b58	210
28	Vox 4>	58	210
29	Vox 5>>	58	210
30	Vox Dr	58	210
31			
32	T/B	58s	-

	Mix Bus	Out put
1	SR	SR
2	SL	SL
3	C.Foot	C.Foot
4	Dr	Dr
5	Key	Key
6		
7		
8		
9		
10		
11	outboad 1	
12	outboad 2	
13	Rev 1	REC L
14	Rev 2	REC R
15	Rev 3	FOH L
16	D.D	FOH R

	DCA
1	FREE
2	"
3	"
4	Rev 1
5	Rev 2
6	Rev 3
7	D.D
8	S/E

	Internal REC
	USB
	SDcard

	MTRX
1	Rec L
2	Rec R
3	-
4	-
5	-
6	-

	AUX In	Ret	Type
1	SE MIX L		TRS
2	SE MIX R		
3	SubMix L		
4	SubMix R		
5	Outboad 1		
6	Outboad 2		
7	USB L	internal	
8	USB R	"	

	AUX Out	Send
1	-	
2	-	
3	Outboad 1	
4	Outboad 2	
5	-	
6	-	

Gold-Creek console M-32 W.C48khz sub con LS-9 Local 14in SEmix con MX1604A
---

mic	
451	3
AT2021	2
58	8
57	4
e604	4
B91	2
B52	1
B58	2
B57	2
D I	8

wedge	
SX300	6
ZLX15P	1
ZLX12P	1